


## **PLACING YOUR ORDER**

Call 1.800.95.SPRAY for application assistance or to place an order.

FOR DETAILED SPRAY SET-UP PERFORMANCE DATA
SEE SECTION D

## **OVERVIEW: J AND JJ SERIES NOZZLES**

- Liquid and compressed air enter the nozzle body and are mixed by the spray set-up to produce a finely atomized spray pattern
- Spray set-ups, consisting of an air cap and a fluid cap, can mix the fluids either internally or externally
- Hundreds of spray set-ups are available to produce cone and flat spray patterns
- A wide variety of nozzle bodies are available for convenient mounting and positioning
- JJ compact nozzle bodies are available for applications where space is limited
- Models available with clean-out needles, shut-off needles, swivels and strainers to optimize performance



Air and liquid enter the air atomizing nozzle body and are combined by the spray set-up to generate finely atomized droplets.

## **QUICK REFERENCE GUIDE**


Product Number	Inlet Connection Size (in.)	Max Flow	Max Temp (liquid)	Spray Set-Ups
1/4J Series	1/4 (F)	72 gph	160°F	1/4J set-ups
	NPT or BSPT	(273 lph)	(71°C)	(page D32)
1/8JJ Series	1/8 (F)	33.2 gph	160°F	1/8JJ set-ups
	NPT or BSPT	(126 lph)	(71°C)	(page D35)
1/2J Series	1/2 (F)	306 gph	160°F	1/2J set-ups
	NPT or BSPT	(1158 lph)	(71°C)	(page D43)
1J Series	1 (F)	29 gpm	160°F	1J set-ups
	NPT or BSPT	(110 lpm)	(71°C)	(page D49)

#### 1/2J SERIES NOZZLES

- J Series nozzles consist of a nozzle body and a spray set-up
- A wide variety of spray set-ups are available with flow rates up to 306 gph (1158 lph) in various spray patterns
- Basic 1/2J bodies have liquid and air inlets on opposing sides
  of the nozzle bodies. Nozzle bodies include a removable
  plug so needle assemblies can be added in the future
- · Nickel-plated brass or stainless steel construction



## 1/2J NOZZLE OPTIONS





**1/2JN** – Manual shut-off needle to stop liquid flow



**1/2JCO** – Manual clean-out needle to clear obstructions from the fluid orifice



**1/2JBC** – Air and liquid inlets at the back of the nozzle body, in line with the spray direction



**1/2JBCJ** – Steam jacket around the nozzle body for spraying liquids too viscous to spray at room temperatures



**1/2-2J** – 1/2" air and liquid inlet connections on opposing sides of the nozzle body with two opposing spray set-ups

# WALL MOUNT ADAPTER OPTIONS

**Thick wall adapters** for 1/4J with 3/4" NPT or BSPT (M) adapter connections use CP4886 wall mount adapters. Replace retainer rings on nozzle assemblies and fit into threaded wall openings. See page G22 for more details